

BLINC-A2

Power On

Push and hold the “Power” button for at least 2 seconds to power on. The Blue LED turns on and you will hear ascending beeps an “Power on”

Power off

Push the “Power” and “Phone” buttons at the same time for 2 seconds, the red Led turns on for about 1 second until it turns off completely and you will hear “Power off”.

Pairing with Phone

Please make sure the Blinc-A2 is in power off position. Push the “Power” button for at least 5 seconds till the LED flashes in red and blue alternately and you will hear a voice prompt saying “Pairing” in the speakers. Enable your Bluetooth function on your mobile phone. Your mobile phone will now scan nearby devices and find a device named “BLUETOOTH HELMET”. Please allow your mobile phone to pair with the device. When pairing has completed and the Blinc-A2 is ready for use you will hear a voice prompt saying “Pairing successful” in the speakers.

Once pairing between the two devices is successful, the LED lights on the Blinc-A2 will change from red and blue flashing lights to a blue LED light only.

Note: if a PIN code is required by your mobile phone, please enter “0000”.

If you paired with your phone and Blinc-A2, Blinc-A2 will connect your phone automatically when you turn it on again.

Pairing with a second Bluetooth device or mobile phone

Multipoint Bluetooth pairing allows the Blinc-A2 to connect two Bluetooth devices at the same time.

You can pair the first and second Bluetooth device or mobile phone to the Blinc-A2 by following the simple procedures in “Pairing with your mobile phone”.

After second Bluetooth device or mobile phone confirms that pairing has completed, select the Blinc-A2 in the list of the devices on your first Bluetooth device or mobile phone.

After the first Bluetooth device or mobile phone confirms the pairing has completed and the Blinc-A2 is ready to use for two Bluetooth devices or mobile phones.

Intercom

The BLINC-A2 can be paired with another headset for Bluetooth intercom conversation.

1. Turn on the two Blinc-A2 headsets (A and B) that you would like to pair with each other
2. Press and hold the “Power” button of the headset A and B for 2 seconds until the LED flashes red and blue alternately. You will hear a voice prompt saying “pairing”
3. Simply press the “Power” button in only one headset (it doesn’t matter that you choose A or B) you will hear a voice prompt saying “Searching” and wait until the LEDs of both headsets turn to blue and intercom connection is automatically established, and after you will hear a voice prompt “Pairing successful”. Procedure is completed.

If the pairing process is not completed within two minutes, the Blinc-A2 will return to stand-by mode.

To use Intercom simply press “Power” button in only one headset, you will hear “Intercom connected”; if you press “Power” button on both headset, intercom will not start.

Connection with phone

Blinc-A2 will connect with your phone automatically when you turn on. If Blinc-A2 is turn on, you can simply press “Phone” button, it will connect with your phone

Voice Commands

Press and hold "Phone" button for 2 seconds in stand-by mode that will start voice commands on your smartphone.

To redial the last number

Double click the "Power" button in stand-by mode that will redial the last number. You will hear a voice prompt saying "Redialing".

Answer an incoming call

When you have an incoming call, simply press "Phone" button to answer a call, or Blinc-A2 will automatically answer the incoming call after 8 seconds.

Reject an incoming call

To reject a call, please double click the "Phone" button. You will hear a voice prompt saying "Call rejected".

Terminate a call

To end a call, please simply press the "Phone" button when calling. You will hear a voice prompt saying "Call terminated"

Play/Pause Music

To play music or pause music, simply press "Phone" button in stand-by mode.

To track forward or track back

Long Press "Phone" button about 2 seconds when playing music, you can rotate "phone" button to track forward or track back in 5 seconds, counter-clockwise will track forward, and clockwise will track back.

Starting and ending Intercom conversation

1. You can start an intercom conversation with your intercom friend by press "Power" button once.
2. To terminate an intercom conversation, press "Power" once again.

Adjust Volume

You can adjust the volume when intercom calling, music playing, counter-clockwise will increase volume, and clockwise will decrease volume. Please loudly speak when speaking and nearby the microphone, otherwise the microphone will stop working in 5 seconds if the sound is low, and when you'll speak again, the microphone also will working again.

Pair with BL300

Press "Phone" button about 7 seconds until blue LED stop lighting in stand-by mode. Then operate ET300 complete pairing.

Remote control with BL300

Press the grey button (Music button) to play music in your mobile phone if there no music palying. Push the grey music button again to pause the music.

Double click the green button when Blinc-A2 in stand-by mode that will start the voice call.

When there is an incoming call, you can press green button to answer the call.

Double click the green button to reject an incoming call.

Press the green button to terminate the call when calling.

Press the green button to establish the intercom when Blinc-A2 is in stand-by mode, and press again to terminate the intercom.

If you paired the Blinc-A2 with ET200, when you press the RED button, the walkie talkie will be into sending state. After you release it, the walkie talkie will be into receiving state.

Press Volume+ button to track forward song; long press this button to increase the volume

Press Volume- button to track back song; long press this button to decrease the volume.

Voice prompt indicator for battery capacity

When you power off the headset, simply press the “Power” button for 1 second, then you will hear a voice prompt indicating the battery level:

“Battery full”:	70/100%
“Battery fifty percent”:	30/70%
“Battery low”:	00/30%

Low battery warning

When the battery is low, the red LED will blink for every 30 seconds, and you will hear a voice prompt saying “Battery low”.

Charging the BLINC-A2

You can charge the Blinc-A2 by connecting the supplied USB cable into a computer USB port or USB wall charger. LED indicator shows stable red while the device is charging and LED indicator turn off when battery is fully charged. It takes about 3 hours to fully charge.

Connection with other devices.

If you have a standalone Bluetooth device follow the pairing procedure separately. The procedure is the same as the procedure of “Mobile phone pairing”

Device update

All Blinc owners get access to free firmware upgrades, which ensure your Blinc-A2 will be always operating at peak performance.

System reset

Press once the reset button to reset the system.

1 The microphone must be positioned very close to the mouth and in the right way



2 There is a white dot in the flexible microphone stand that indicates the side that must be close to the mouth



3 The Wind cap has a flat side



4 Flat side must be placed on the microphone side and close to the mouth

